

Fig. 1




Fig. 2






Fig. 3


Fig. 4





5
bio
E

Fig. 6






Fig. 7





Fig. 8

		Y _A Y _B			
		00	01	11	10
X _A X _B	00				
	01				
	11				
	10				

$$\begin{aligned}
 F_{\text{OVERFLOW}} = & X_A \cdot X_B + Y_A \cdot Y_B \\
 & + X_A \cdot Y_A + \\
 & X_B \cdot Y_A + Y_B \cdot X_A
 \end{aligned}$$

Fig. 9

Fig. 10






Fig. 11




Fig. 13

